

Model Configuration	la belle 201	la belle 210	la belle CL 210	la belle 410	la belle CL 410	la belle 420	la belle CL 420	la belle BC 211	la belle BC 421	Junior BC 211	Junior BC 421	headset la belle BC 211	freestyle CL 201	freestyle CL 210	freestyle CL 410	freestyle TID (201)	freestyle CL 210 + TID
	BASIC			COMFORT		PREMIUM		COMFORT	PREMIUM	COMFORT	PREMIUM	COMFORT	BASIC	COMFORT			
WDRC	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
AFC	-	●	●	●	●	●	●	●	●	●	●	●	-	●	●	-	●
NRC	-	-	-	●	●	●	●	-	●	-	●	-	-	-	●	-	-
MPO progr.	-	●	●	●	●	●	●	●	●	●	●	●	-	●	●	-	●
Trimmer TC	●	-	-	-	-	-	-	-	-	-	-	-	●	-	-	●	-
VC	●	○	○	○	○	○	○	●	●	●	●	●	●	○	○	●	●
Trimmer MPO	●	-	-	-	-	-	-	-	-	-	-	-	●	-	-	-	-
Trimmer GC	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Gain adjustment bands fix	12	-	-	-	-	-	-	-	-	-	-	-	12	-	-	12	-
Gain adjustment bands variable	-	12	12	12	12	12	12	12	12	12	12	12	-	12	12	-	12
Program button	-	●	●	●	●	●	●	●	●	●	●	●	-	●	●	-	●
Program button tones	-	●	●	●	●	●	●	●	●	●	●	●	-	●	●	-	●
Low battery warning	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Programming socket	-	●	●	●	●	●	●	●	●	●	●	●	-	●	●	-	●
Programs	1	3	3	4	4	4	4	3	4	3	4	3	1	3	4	1	3
Raising delay	-	-	-	●	●	●	●	-	●	-	●	-	-	-	●	-	-
Telecoil	-	-	-	-	-	-	-	●	●	●	●	●	-	-	-	-	-
Channels	2	2	2	4	4	4	4	2	4	2	4	2	2	2	4	2	2
Mikrophones	1	1	1	1	1	2	2	1	2	1	2	1	1	1	1	-	1
CROS, BiCROS	○	○	○	○	○	○*	○*	●	●	●	●	●	-	-	-	-	-
Directional microphone system	-	-	-	-	-	●	●	-	●	-	●	-	-	-	-	-	-

Configuration Code

- standard
- optional
- not included
- * only CROS available

Code for device identification

1. place Number of channels
 2. place Device programmable (o = no | 1 = yes | 2 = yes + 2-microphone-technology)
 3. place Volume control (o = no | 1 = yes)
- freestyle 201 = 2 Channels, not programmable, Volume Control

Stand 08/09